## \* DCM ( DISCOVERY CENTER )





Rear Ports
1. A/V Output
2. DC In
3. DVI In
4. VGA In
5. S-Video In


6. Audio In 7. Audio Out

- 1. A/V OUTPUT : PORT TO CONNECT TO ADDITIONAL DISPLAY SUCH AS TV OR OTHER MONITORS.
- 2. DC IN : PORT FOR 12VDC POWER ADAPTER.
- 3. DVI IN : PORT TO CONNECT TO SOURCES THAT HAVE DVI OUTPUT.
- 4. VGA IN : PORT TO CONNECT TO PC COMPUTERS.
- 5. S-VIDEO IN  $\,:\,$  PORT TO CONNECT TO SOURCES THAT HAVE S-VIDEO

**OUTPUT SUCH AS: DVD PLAYERS, VCD PLAYERS etc.** 

6. AUDIO IN : PORT TO CONNECT TO AUDIO OUTPUT FROM DVD PLAYERS, VCD PLAYERS etc.


7. AUDIO OUT: PORT TO CONNECT TO EXTERNAL SPEAKERS.






- 8. SD CARD: SLOT FOR SD CARD TO SAVE IMAGES.
- 9. POWER : SWITCH TO ACTIVATE WIRELESS IMAGES CAPTURE AND SD CARD IMAGES STORAGE SYSTEM.
- 10. ANTENNA FOR BUILD IN WIRELESS RECEIVER.
- 11. LED DISPLAY FOR CURRENT WIRELESS CHANNEL.
- 12. INFRARED RECEIVER FOR REMOTE CONTROL.
- PS: POWER BETWEEN LCD DISPLAY AND WIRELESS IMAGES CAPTURE SYSTEM ARE SEPARATE THEREFORE ALTHOUGH WIRELESS IMAGES CAPTURE IS SHUT DOWN, LCD DISPLAY STILL CAN USE FOR OTHER PURPOSE.

## \* REMOTE CONTROL AND APPLICATIONS





## **NOTE:**

- THE LARGER THE CAPACITY STORED INSIDE SD CARD, IT WILL TAKE MORE TIME TO START FOR DISCOVERY CENTER.
- 2 GB IS MAXIMUM CAPACITY RECOMENDED FOR SD CARD.
- PLEASE INSERT SD CARD BEFORE STARTING DISCOVERY CENTER.
- DISCOVERY CENTER ONLY CAN READ THE IMAGES THAT CREATED BY IT SELF. IT CANNOT READ IMAGES THAT CREATED BY OTHER SOURCE.